

1. ORDERING INSTRUCTIONS

1.1 Part Numbers – Barrels are normally ordered using part numbers 48210-0, 48140-0 and 48247-AB. These assemblies include the lid. For part number #48247-AB the assembly has two half barrels that lock together to form one barrel.

2. FIELD SITE CONDITIONS AND LAYOUT

2.1 Surface Conditions – Inspect the area where the sand barrels will be placed. Make sure that the surface is concrete or asphalt if specified in the plans. Also make sure that the grade is not more than 3 degrees and that the surface is smooth and on plane.

2.2 Array Layout – Review the plans and determine the center line for the rows of barrels. Mark the center line with a chalk line. Position the barrel lids centered on the line with the correct spacing between the lids. Mark around the lids with chalk to establish the barrel positions. Remove the lids and place the sand barrels in the correct position.

3. FIELD ASSEMBLY

3.1 Barrel Assembly – All part #48247S half barrels have six butyl caulk strips that are used as contact adhesives. When upper half barrels #48247S are installed on top of #48247P and rotated the two barrels will interlock and the two can be lifted without separation.

3.2 Barrel Disassembly – After half barrels #48247S and #48247P have been interlocked they will be difficult to separate unless the following procedure is followed. Use the barrel lifting ring to elevate the assembly and pry the half barrels apart along several locations around the circumference.

3.3 Sand Filling – All barrels are marked with the sand fill lines indicated on the outside of the barrels. Place all barrels in the correct location as designated in the site plans. Sand filling is best done by having a concrete truck deliver the sand and pouring the sand into the barrel. **WARNING** - sand used in barrels needs to disperse on impact do not use sand unless it has been washed and has less than 5% water content.

3.4 Lid Attachment – Lids are designed to fit tightly to prevent theft. Place lid on barrel with the lid fitted on the barrel at the inside of the array position. Apply pressure at the rim to snap the lid on. Work on each side up to the front. Push down for final set of lid.

3.5 Lid Removal – If the lid needs to be removed a pry-bar or fiberglass batten will easily remove the lid. Slip the pry-bar vertically between the lid and the rim of the barrel and start prying along rim.

4. LIFTING BARRELS

4.1 Work Zones – Check to see if wooden pallets are approved for work zones, if they are, move pallet into position with a fork lift. For work zones not using pallets, move barrels with the optional aluminum lifting ring.

4.2 Permanent Sites – For locations where the barrels are set on a prepared surface use the lifting ring to position barrels. Barrels use two different diameter lifting flanges. Use the aluminum insert in the lifting ring when lifting the smaller diameter flange found on the 700-400 lb. (320 – 180 kg.) capacity barrel.

5. INSPECTION

5.1 Sand Height – Sand barrels can be easily inspected using several methods. Refer to the marking on the barrel for the correct sand height. Hit the side of the barrel and view the barrel on the shaded side. A change of sound and a difference in light transmission should be noticed at the top of the sand.